



SBWB Water Back

This unit is designed to permanently attach to your Vision recumbent bicycle seat back. It provides a tool pouch and a sleeve for standard "backpack" style water bladders. The WaterBack does not come with a water bladder, even though one is shown in these pictures. The WATERBACK also provides mounts for the new "SB" line of seat bags from Vision.

To mount your *WATERBACK*, follow these instructions:

1. Check fit. This unit is designed to fit tightly across the top of your Vision recumbent seat. Due to manufacturing tolerances the fit of the "pocket" over the seat back may be tight or *very tight*.

2. Slide the "Pocket" over the seat back.. Pull the pocket of the *WATERBACK* over the top of the Vision seat. If the fit is too tight to easily pull into place, you can pull the top strap on the seat tighter (temporarily) to ease the installation. Once the pocket is settled in place, reach inside from the back and re-set the top seat strap to its normal position. If you have an older (pre 1999) Vision seat fabric without the "belt" style straps, you can brace one seat rail against a wall and lean on the other seat rail to get the needed clearance to install the *WATERBACK*.

3. Attach the lower section. Thread the end of the *WATERBACK* bib outside of the seat fabric and inside of the seat frame rails. Loop the end strap around the seat base strap and fasten the velcro. You can now install your water bladder, tools and any of the Vision "SB" seat back bags.



Advanced Transportation Products, Inc.

Phone: 425-673-2448 Fax: 425-673-4668

E-Mail: Info@visionbikes.com Web: <http://www.visionbikes.com>

Made In USA